

BACKLIT COLOR TRANSFER TIPS

STEP 1:

Take the individual color plot files and add a bleed. (Make sure the individual colors do not overlap each other.)



STEP 2:

Create a plot file for the matte black vinyl (or opaque vinyl of your choice) and plot the original lines from the artwork without the bleed.



STEP 3:

Color transfer all the plotted vinyls into one vinyl transfer (with the opaque or matte black on top), which can then be easily applied onto the plexiglass panel that slides into the face of your sign!

